LED FLASHLIGHT

P3APP005000A LED Flashlight
P3APP005001A LED Flashlight Bracket



TECHNICAL SPECIFICATION

LIGHT SOURCE	Cree XLamp® XQ-E LED
CANDELA	3000
OPERATING TIME	5 hours
POWER SUPPLY	3 x AA/LR6
DIMENSIONS	170 x 44 mm
WEIGHT	180 g LED Flashlight

Thank you for choosing an Accenture product. Proper operation and maintenance ensures high durability and reliability. Please read the operating manual and keep them for future reference, as they contain important information regarding safe operation and use.

NOTICE

It is not recommended to use the flashlight for purposes other than intended. The manufacturer expressly withdraws the warranty if it is used contrary to the recommended purpose.

FLASHLIGHT OPERATION

To turn on the flashlight, press the button marked with the light bulb symbol. To turn off the light, press the button again. To check the battery level of the installed batteries, hold down the button marked with the battery symbol. The red LED indicates the need to replace the battery.

REPLACING THE BATTERY

To replace the batteries in the flashlight, unscrew the END CAP of the battery compartment by turning it counterclockwise. Remove the used cells from the compartment and replace them with a set of 3 x AA/LR6 batteries. When inserting the batteries, observe the polarity of the cells according to the diagram located inside the compartment. Place the END CAP back into position, ensuring that the battery contact spring is oriented towards the minus end of the battery. Tighten the END CAP until it stops. Verify the correct installation of the new cells by using the battery indicator. The light indicator should turn green.

CAUTION!

Make sure you use only genuine parts designed for the flashlight. The use of spare parts from other manufacturers may affect the quality and parameters of the product. In accordance with EU's WEEE regulation, storage batteries must not be disposed of with normal household waste. Instead, they must be disposed at designated battery collection points. Check with your local garbage disposal company about the method and type of reprocessing or other instructions.

GENERAL INFORMATION

Modifications and repairs:

All modifications and user-attempted unauthorized repairs, for which Accenture has not granted written consent, automatically invalidate the warranty. Accenture does not authorize any independent user interventions in the product or attempts at repairs outside of the manufacturer's authorized service. All foreseen repairs are mentioned in the competent maintenance manual (CMM) 25-60-04.

USING AND HANDLING THE BATTERY

To reduce the risk of fire, electrocution or other bodily harm, carefully read the flashlight operating manual.

- Always make sure the battery's polarity is correct.
- Remove the batteries if the flashlight is stored for extended time.
- Do not recharge alkaline batteries.
- Do not dispose of the batteries in fire.
- Keep the batteries out of reach of the children.
- Do not force the batteries open.
- Keep the flashlight away from UV radiation, humidity and chemical products.

